

Beikell USB 3.0/USB C Card Reader

Model No.: B6316

Instructions for Use:

1. Insert the SD / TF / MS / CF card into the corresponding port on the card reader.
2. Insert the card reader into the USB A port available on the host PC or the USB C port of a tablet or Android phone that supports the OTG function.
3. Once the card reader is successfully connected, the blue LED lights up and you can transfer or edit the data on the media card.

Note: You need to insert the SD / TF / MS / CF card into the card reader before using it, and then connect the external device.