

Bubble Machine Instructions

Use:

1. Place the bubble machine on a solid, flat surface and in a well-ventilated area.
2. Pour bubble liquid into the liquid reservoir. Always ensure the liquid level immerses at least one wand. Do not fill the reservoir over the noted maximum level.
3. Switch clockwise to Speed Level 1. Turn the switch again for Speed Level 2 if desired.

Attention:

- Keep the air intake ports free from blockage.
- Do not use outdoors in the rain as this may lead to a short circuit.
- Do not leave unused liquid in the reservoir for an extended period. The liquid may thicken.
- Remove all liquid before storing or moving.
- The bubble machine should not be used more than 8 hours consecutively.

Cleaning:

1. Empty all bubble liquid from the machine
2. Rinse and drain the reservoir using a little distilled water.
3. Add some warm distilled water to the maximum level.
4. After adding water, turn on the bubble machine and allow it to run in a well-ventilated area until all wands appear to be free of residue.
5. Drain the remaining water to complete cleaning.