

User Manual



BUNUD External CD DVD Drive USB 3.0 & Type-C

Please read this User's Manual carefully before using and keep it for future reference!

After-sales service email: homeyuanservice@outlook.com

Note:

1. This DVD drive can't work for iPad /Tablet /Projector /TV /Chrome OS /Car /Smart Phone .
2. Don't support the Blue-ray format.
3. Don't put this drive by the strong magnetic objects.
4. Keep this item steady on the desktop, do not put it unstable items.
5. The maximum readable capacity of the item is 8.5G.
6. For Apple MacBook Type-C interface, please eject disk from your computer.
7. For desktop, please connect the back USB port of the main board instead of front USB interface.
8. The internal laser beam could be hazardous to your eyes, please don't stare directly to the beam.
9. Don't put this item on the vulnerable squeeze place, to ensure successfully normal use.
10. Please hook up this CD drive to direct USB C or USB port on your computer.
11. Don't connect it to a USB hub or extension cords, it can't recognize the Drive.
12. Must make sure there is a correct connection for this DVD drive, if not, It can't work with computer.

Product List:



External DVD Drive x 1



Power Cable x 1

Please check whether the external CD DVD drive is in good condition and the accessories are complete according to the above figure !

Product Features:

1. This is a 5-in-1 External DVD Drive with USB and USB C ports. It is with 1 extra SD card reader, 1 extra TF card reader and 2 USB 3.0 ports. It supports SD card, TF card, 2 USB 3.0 port transfer / charging, disc's read and write.
 - 1) When plug the DVD drive into your computer, at the same time,you can also plug the SD / TF card into the SD / TF slot, transfer directly into the USB flash drive / Hard drive / computer and external DVD drive. It also can transfer from DVD drive / computer / USB flash drive / Hard drive to the SD / TF card,just plug and play. **Note:The SD card and TF card can't work at the same time.**
 - 2) There is 2 extra USB 3.0 ports next to the SD / TF slot, we can use them as a USB Hub with transferring and charging. We can plug USB flash drive / Hard drive / Mouse / Keyboard / Phone into this 2 ports. It helps us to use other USB devices while playing external CD player in fewer port computer. We can use this 2 extra USB 3.0 ports to transfer from USB flash drive / Hard drive to SD / TF card / computer / DVD player, also can transfer from computer / DVD drive / TF / SD card to USB flash drive / Hard drive. **(Due to the versatility of the drive, if there is insufficient voltage you need to use the power cable which is in the packing)**
 - 3) The 2 USB ports support 5V 3A devices (USB flash drive, USB Keyboard,Mouse, Hard drive, DVD drive, Phone charging etc.) and work together, just like a USB Hub. This is not an ordinary USB Hub, it can provide enough power to all the devices. You can play 3 DVD drives at the same time, and choose the one you want to play.
 - 4) The 2 USB ports are compatible with USB 2.0 and USB 1.0 devices, you can also plug the USB C adapter for other USB C devices.
2. It is Powered by the USB C / USB port, it is suitable to connect desktop computer or laptop with USB 3.0 / Type-C interface. No driver program required. Don't need to install software to set for driver.
3. No need to install the driver, plug & play. Can burn files, install software, create a backup CD / DVD,watch DVD movies,Listen Music etc.
4. Standard USB 3.0 / USB Type-C port, support hot plug.
5. Compatible with Windows, Mac OS system.

6. Made with Aluminum Alloy material of shockproof. Adopt pure copper mesh technology, low impedance and strong protection, which provide more stable data transmission. Low noise, Anti-interference and high durability.

Support:

DVD±RW/DVD±RDL/CD±RW/DVD-Rom/CD-Rom/CD±R /DVD-RW/DVD±R/ DVD-RAM

※ Reading Speed※:

DVD 8X; CD 24X




※ Writing Speed※:

DVD±R DL 4X; DVD±R 8X; DVD±RW 6X; CD-R 24X; CD-RW 6X

How to put the disc into the DVD drive?

※ On Windows system(included 2 ways)※:

1. Plug the DVD drive into the Windows system computer in a correct way, press the eject button on the panel, the tray will be opened, and put the disc in it, then will play soon.

2. Plug the DVD drive into the Windows system computer, Click on the desktop, open "This computer ", there is a DVD RW icon  display in the "Devices and Drives", double-click the DVD RW icon , the tray will be opened, put the disc in it, then will play soon.




※ On Mac system※:

Plug this DVD drive into Mac system computer in a correct way, press the eject button on the panel, the tray will be opened, put the disc in it, there is a disk icon showing on the desktop, then will play soon.

How to eject the disc out when finished the disc playing ?


※ On Windows system(included 2 ways)※:

1. Press the eject button, will eject the disc out soon.

2. Open "This computer ", find out the DVD RW icon  display in the "Devices and Drives", right click and there is an eject choice , click it and will eject out the disc.

※ On Mac system(included 2 ways)※:

1. Click the eject button on the playback software, and will eject the disc out.

2. Drag the DVD icon  on the desktop to the trash can, will eject the disc out soon.

Possible Problems & Solutions:

1. For the desktop computer, please plug the USB cable directly into the USB interface behind the computer host (**Pic 2**), rather than the front one (**Pic 1**)



(Pic 1) (X)



(Pic 2) (✓)

2. When the input ports are not enough for your computer, you should connect the CD drive directly into the computer input port, don't connect to other device, such as USB HUB / Adapter. (**Pic 1 & Pic 2 & Pic 3**).



(Pic 1) (X)



(Pic 2) (X)



(Pic 3) (X)

3. Note that CD Drive can not be used through the adapter in order to make sure of sufficient power supply (Pic 1 & Pic 2).



(Pic 1) (X)



(Pic 2) (✓)

4. If this DVD drive works on laptop, please plug the drive directly into the USB port or USB Type-C port (Pic 1 & Pic 2 & Pic 3).



(Pic 1) (✓)



(Pic 2) (✓)



(Pic 3) (X)

5. This product is equipped with USB 3.0 & Type-C interface. Both of them can be plug and play.

Question and Answer:

1. Q: I plug the DVD drive into my computer, it can't be recognized and play, is it defective?

A: Please must be sure there is a correct connection from the drive to computer, please plug the Micro USB into the back of the drive, plug the USB 3.0 adapter or USB Type C adapter into computer. Don't plug the USB 3.0 adapter into the drive and plug the USB Type C into computer.

2. Q: Does this drive go to work with Windows 10/11 ?

A: Yes, this DVD drive can work with Windows 10/11 computer. As the new released Windows system have discontinued the internal DVD media player software, customer using Windows 10 and above are advised to Install VLC Media player to Play DVD and CD. And check clearly for the link which regarding the DVD drive cant for windows 10/11 system, check clearly and

6

do as what it suggests, then the DVD drive will work well:

<https://www.drivereasy.com/knowledge/dvd-wont-play-on-windows-10-solved/>.

NOTE: It is important you have a media player such as the free VLC media player installed BEFORE you connect the DVD player. This is not a fault of the DVD player - it's because Windows 10 doesn't have a default player installed.

3. Q: Is it compatible with iPad ?

A: Sorry it can't be compatible with iPad, as there is no drive driver in iPad and it can't provide enough power for this DVD drive .

4. Q: when playing on my Mac, I press the eject button, but it can't eject the disk out.

A: Yes, when the DVD drive is playing on Mac, it can't stop working through the eject button on the panel, Please click the eject button on the playback or drag the disc icon on the desktop to the trash can, that will eject the disk out.

5. Q: Why this drive can play CD well in Catalina, but can't play DVD?

A: As the Apple newest update Catalina can play CD well, but can't play DVD, we need to install another DVD playback software to play DVD. Please follow this steps to play DVD:

Please open your APP Store, you will see the Category, click it and there is a Video file, click it and you will see the playback software in it, (There are free and paid, we commend to choose the free playback software), choose one to install it. After that open the file on the playback, choose the disc to play, that is OK.

NOTE: It is important you have a media player installed BEFORE you connect the DVD drive. This is not a fault of the DVD player. It's because Catalina doesn't have a default player installed.

Precautions:

The external drive depends on whether the operating system of your computer have the function of detecting other device, otherwise you need to download the driver.

Generally speaking, almost all of the older operating system could recognize the DVD drive

7

through direct installation or external connection.

So if the operating system of your computer has the drivers or has the ability to download drivers, the external CD/DVD drive will work.

Methods to Resolve Exceptions:

Please make sure your computer has downloaded CD/DVD driver before using the CD drive. If your computer doesn't have the driver, please contact with us directly via:

homeyuanservice@outlook.com.

Please make sure the laptop possess sufficient capacity, or it may cause the device can't be recognized.

The newly released Windows system has interrupted the use of external DVD media player software. If you are using Windows 10 or above system, please install the VLC Media Player to play DVD and CD.

Please connect the item to the direct USB port of your computer. If you connect it to a USB hub or extended cord, it may not recognize the item, or can't read the CD/DVD.

Attention:

1. Any problem about this DVD drive, please directly to contact via:

homeyuanservice@outlook.com. We offer 60 days full refund and 1 year quality warranty.

2. The SD card and TF card can't use at the same time, only choose one to work for you. Each of them can work well with the 2 USB ports at the same time.

3. Please don't attempt to disassemble the machine when it is not working, damage caused by unauthorized repairs are not included within the guarantee period and they are subject to be charged.

4. Please make sure the laptop is with sufficient power supply, a low capacity may cause the CD player can't be recognized.

5. Data transfer speed is also affected by computer and system environment.

6. When plug this CD drive into Microsoft surface computer, please plug the power cable to ensure to provide enough power for this drive, plug the USB of power into your computer or USB plug.

8

7. When this item works on Apple newest update Catalina system, please make sure there is correct media playback software playing DVD. If not, it can't play DVD. Please do as this follow steps to install a playback software for your Catalina:

Please open your "APP Store", you will see the "Category", click it and there is a "Entertainment", click it and you will see some playback software in it, (there are free and paid, the best please choose the free playback software), choose one of them to install it. After that open the file on the playback, choose the disc to play, that is OK.

8. The new released Windows system have discontinued the internal DVD media player software, customer using Windows 10 and above are advised to Install VLC Media player to Play DVD and CD. And check clearly for the link which regarding the DVD drive cant for windows 10 system, check clearly and do as what it suggests, then the DVD drive will work well:

<https://www.drivereasy.com/knowledge/dvd-wont-play-on-windows-10-solved/>.

NOTE: It is important you have a media player such as the free VLC media player installed BEFORE you connect the DVD player. This is not a fault of the player - it's because Windows 10 doesn't have a default player installed.

Warranty:

60-day money-back guarantee for any reason + 1-year warranty service

If the drive you bought from BUNUD has any problem, we will always be responsible for you, you can feel free to contact us via : **homeyuanservice@outlook.com.**

Please provide your Amazon order number and product brand/name in the Email, we will reply you within 24h! If this device is defective, we will arrange a free replacement for you immediately! Please trust us and give us some time to help you, thank you!

Currently, all our drives are fulfilled by Amazon, if you're not satisfied with this drive, please contact Amazon customer service to return it for the refund within 30 days.

If everything is fine, please send us an email to **homeyuanservice@outlook.com** to get extra 1 year warranty for free.

9